

Field Termination Plug User Guide

P8-079-5
P8-079-6
P8-079-7

1

Copper Foil Tape
30mm
10mm

2

Boot
Cable

3

30mm Min.
10mm
or
10mm
30mm Min.
S/FTP
U/FTP.F/UTP

4

10mm
30mm Min.
Copper Foil Tape

5

7/8 4/5 3/6 1/2
4/5 7/8 1/2 3/6
7/8 4/5 1/2 3/6
7/8 4/5 1/2 3/6
✓
✗

6

↓

7

5~8mm Max.

8

Cut 2
Cut 1
0.2mm Max.

9

Align

10a Hand screwing

1 Close
2 Screw

10b Optional Tool

3
1
2
Use C8 Cable Optional
1 2
Push

11

CABLE INFORMATION FOR INSTALLATION				
	TYPE	CONDUCTORS	WIRE OD(MM)	CABLE OD(MM)
C6A	23~26AWG	STRANDED & SOLID	1.0-1.4	6.0-7.5
C6A	22~24AWG		1.2-1.5	7.0-8.5
C8	22~24AWG		1.2-1.7	